



STORM SMALL OUTPUT

datasheet



Project: Private Residence | Lighting design: ONE A

The STORM SYSTEM® collection is carefully designed to flush the surface of any ceiling or wall, and all products will appear with an absolute minimum of tolerance and visibility.

The Storm Small Output is designed to hide the canopy of your pendants. Visually the wire disappears into the ceiling.

GENERAL DATA

Collection

STORM SYSTEM®

Product

Storm Small Output

Article no.

1A00.0500.xx

SPECIFICATIONS

Weight

146 g / 5.15 oz

Material

Aluminium



IP protection grade

IP20

Load

Please refer to the chosen installation ring's datasheet

Labelling



ADDITIONAL REQUIREMENTS: (not included)

Installation rings – choose one of the installation rings below

- Storm Small Plaster Ring – 1A00.0002.01
- Storm Small Back-Mounted Ring – 1A00.0049.xx
- Storm Small Back 007 Ring – 1A00.0047.04
- Storm Small Extension S120 – 1A00.0017.xx
- Storm Small Extension S300 – 1A00.0035.xx

NOTE

By installation of pendants it is important to be aware of pendants load/weight. If your pendant exceeds the specified load – an additional anchor must be completed! For max. load please refer to the installation ring's datasheet.











Pendant cord must be a min. of Ø3 mm / 0.12" and a max. of Ø8 mm / 0.31" .

Storm Small Output can be installed in sloped ceilings with an angle of up to 45°



XX – COLOUR CODES

- Full colour (Alu or Brass)

-  01 – white
-  92 – black pearl
-  08 – mouse grey
-  09 – earth
-  05 – amber
-  06 – platinum
-  07 – carbon
-  33 – nature*
-  34 – antique*
-  35 – night*

(*) Brass is a natural product and colour will change over time

ONE A reserves the rights to change and/or update product information and accepts no liability for any printing errors.
last updated 05 – 02 – 2025





COMPONENTS

- Storm Small Output

IMPORTANT INFORMATION

Installation and mounting must be performed by a certified electrician only, and instructions must be followed. Always make sure the main power is off during installation. Pay attention to the fixture remarks, and always make sure to use the correct voltage.

CLEANING AND MAINTENANCE:

Use a soft moist cloth for cleaning. No further maintenance is required.

WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.




The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal

For more information, please contact info@onea.dk

ASSEMBLY INSTRUCTION


STEP 1

Adjust the length of the cord, leaving the fixture at the desired height. Fasten the cord properly, and test that the load of the chosen fixture is held in place.




NOTE

Please note, if pendant weight exceeds the max. load specified in the chosen installation ring's datasheet, the steel wire must be anchored in additional ceiling support.




STEP 2

Make sure the power is OFF!
Connect the cables




STEP 3

Then mount the fixture into the plaster ring/ back-mounted ring. Do this by slightly rotating the fixture until it locks.



STEP 4


Please ensure that the fixture aligns with the ceiling.



DISASSEMBLY INSTRUCTION

STEP 1


Take hold of the pendant cable and twist it until it stops. Gently push the Output (and pendant cable) upwards, then turn gently until it reaches the position where it can come out.



STEP 2

Make sure the power is OFF!

Disconnect the cables



IMPORTANT INFORMATION

Installation and mounting must be performed by a certified electrician only, and instructions must be followed. Always make sure the main power is off during installation. Pay attention to the fixture remarks, and always make sure to use the correct voltage.

CLEANING AND MAINTENANCE:

Use a soft moist cloth for cleaning. No further maintenance is required.

WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal

For more information, please contact info@onea.dk